

2030 SPEERS ROAD | OAKVILLE, ONTARIO | L6L 2X8 | 1-888-945-5725 | 905-827-0224

13467 05-UP FORD MUSTANG GT CHIN SPOILER (GT ONLY)

CONTENTS:

1 -	Chin Spoiler	4 -	5/16" Lock Washers
4 -	5/16" Hex Bolts	4 -	5/16" Hex Nuts
12 -	5/16" Fender Washers		

TOOLS REQUIRED FOR INSTALLATION

- 3/8" Drill Bit
- 7/32" Wrench
- Drill
- Marker
- 1/2" Wrench

INSTALLATION & HARDWARE MOUNTING INSTRUCTIONS

Please read thoroughly before beginning

1. Remove the factory hardware holding the front center splash shield to the lower front bumper cover (4 pcs).
2. Fit your new chin spoiler to these holes and fasten using original factory hardware, adding one fender washer to each screw prior to re-installing.
3. Do not fully tighten these four screws.
4. Install supplied bolts, washers and lock-washers and secure starting at the outer holes in the factory bumper cover.
5. Do not fully tighten these bolts.
6. Check alignment of chin spoiler.
7. Drill two 3/8" holes through the factory bumper cover using the chin spoiler as a guide.
8. Install bolts, fender and lock-washers, nuts.
9. Tighten ALL hardware. **DO NOT OVER-TIGHTEN.**

NOTE:

This chin spoiler will reduce available ground clearance in front of the vehicle. Use caution when approaching driveways, speed bumps, parking blocks or similar items on the road.

