

14564

08-UP

DODGE

CHALLENGER

HARDWARE SUPPLIED:

• 8 Black push plugs

• 4 Speed clips

CAR MUST BE THOROUGHLY WASHED AND DRIED PRIOR TO INSTALLATION!

NOTE: READ THROUGH ENTIRE INSTRUCTIONS BEFORE PROCEEDING!

1. INSTALLATION INSTRUCTIONS:

1. Remove factory side skirts and fasteners.
2. Pre-fit side skirt to ensure proper fit. Air and surface temperature must be 70°F (21°C). After installation, the vehicle must remain warm and dry for 24 hours. This will allow for proper adhesion of 3M tape.
3. Use masking tape to hold skirt in place. Locate holes in steel fender and plastic inner fender and transfer location to side skirt. Remove skirt. Drill holes in skirt to 9/32"
4. Clean areas to be taped with spirit wipe.
5. Install speed clips to lower holes of plastic inner fender. One (1) at front, one (1) at rear.
6. Remove backing from 3M tape and install to inside door sill area. Apply sufficient pressure to taped areas to ensure proper tape contact.
7. Install one (1) push plug in top hole of skirt through hole in fender. Install second push plug through lower hole and into speed clip in inner fender panel. Repeat at rear.

2. PAINT TIPS:

- Wipe down parts with spirit wipe to remove impurities or any mold releases.
- Wet sand parts with 400grit paper or ultra fine Scotch Brite pad.
- Don't forget your edges.
- Plastic primers are not necessary but can be used.